



AUTOMATIC SPREADERS AM 5000 COMBI AM 6000 COMBI AM 8000

Protection for
road users



AM 5000/6000 Combi and AM 8000 automatic spreaders have extremely precise automatics. This enables the driver to concentrate fully on proper antiskid treatment, which in turn protects the environment.

Simple structure and technical functions ensure that work is always performed according to your specifications. The ergonomically placed switches and adjusters are easy and safe to use.



ROAD INTELLIGENCE

Versatile and controlled use

The hydraulically powered AM 5000/6000 Combi and AM 8000 automatic spreaders are centrally controlled from the cockpit. You can easily adjust the precise spreading amount and spreading width with the electronic joystick while driving.

The screw conveyor moves the material to the spinner, which then spreads it accurately onto the road. The automatic spreader's frame, technical solutions, and operational reliability are all designed for professional use in harsh conditions.



Pictures may contain accessories.

Technical information	AM 5000 COMBI	AM 6000 COMBI	AM 8000
Dry material capacity	5.0 m ³	6.0 m ³	8.0 m ³
Liquid capacity	5.5 m ³	6.5 m ³	2.8 m ³
Working width	2–8 m	2–8 m	2–8 m
Spreading head adjustment	200°	200°	200°

Head Office:

Arctic Machine Oy, Karsikonmäentie 1, FI-77800 Iisvesi, Finland
Tel. +358 (0)20 7791 500, fax +358 (0)20 7791 501
am@arcticmachine.com, www.arcticmachine.com

Copyright © Arctic Machine Oy. All rights reserved.

